



Wall Products International, INC.

201 NE 21st St, Fort Worth, Tx 76164

phone: 800.446.7124 or 817.626.1987

fax: 817.626.0821

www.murcowall.com email: murco@murcowall.com

## SPECIFICATION AND DATA SHEET

### PRODUCT NAME:

Texture Ready Mix Mud Spray

### MANUFACTURER:

Murphy Wall Products International, Inc.  
201 NE 21st St, Fort Worth, Tx, 76164  
800.446.7124

### ADVANTAGES:

- Faster and easier
- Ready to use
- Better water resistance
- Superior adhesion

### PRODUCT DESCRIPTION:

A ready mixed texture for use on interior walls and ceilings. Can be sprayed or rolled on to create texture designs such as splatter drag, splatter knock-down, and orange peel. Can be used for hand troweling. Ready mix textures are both faster and easier to use while reducing the wear and tear on spray equipment.

### TECHNICAL DATA

**Material:** Vinyl type air dry formulation.

**Surface Preparation and Application:** All surfaces must be clean, dry, and free from oil or grease, and efflorescence. Prime metal with rust inhibiting primer. Fill and seal wood surfaces. For concrete, grind plane differences and clean thoroughly. Fill and level with setting type compound. Reinforce and conceal drywall joints using reinforcing tape and joint compound. Fill all fastener depressions with joint compound. Smooth surface scratches and scuffs. Correct plane irregularities, as these are accentuated by sharp angular lighting. This includes texture, joints and corners. In case of liquid separation, remix until smooth. Allow to dry thoroughly before applying second coat. A good quality high solid drywall preparation primer-surfacer is recommended before texturing and finishing.

**Coverage:** Murco Texture will finish approximately 100-150 square feet, per box, depending upon finish desired and conditions.

**Precautions:** Do not apply when temperature is below 55°F. Colder temperatures can cause pinholes and loss of adhesion. Do not ingest. Keep Out Of Reach Of Children. Wet sanding or sponging is recommended rather than dry sanding. Avoid creating dust, do not sweep. A NIOSH approved dust respirator should be used during sanding. HEPA vacuum filtration is recommended. Over addition of water can cause shrinkage, cracking, loss of adhesion, pinholes, craters and other problems.

**Compliance and Standards:** Meets or exceeds the requirements ASTM C-475 and Federal specifications SS-J-5709.

### SPECIFICATIONS

#### Texturing

**Mixing:** Transfer compound into a mixing vessel. Use heavy duty drill to mix, keep blade submerged to prevent air entrapment. Mix at low speed and do not cover mix as this may result in a viscosity loss. Thinning of texture with water will vary considerably, depending on the finished appearance desired and method of applications to be



employeeed. Mix until consistency is smooth and uniform.

**Thinning:** For heavy texture, add up to half gallon of water per 50 lbs. of texture. For roller or crow's foot texture, add up to 1.5 gallons of water per 50 lbs of texture. For spray/splatter texture, add up to 2 gallons of water per 50 lbs. of texture. When thinning always test and adjust water proportions.

**Finishing:** All surfaces must be thoroughly dry and dust free; this includes textures, joints and corners. Avoid finishing over damp walls, this includes priming and painting. Use drywall preparations primers that will not trap and hold moisture, as these can saturate both the texture and the wallboard, and could damage both. Do not paint over damp walls. Check walls for moisture content and allow airflow to help cure slow drying or soft primers and paints, which could take months to cure. Follow manufacturer's instructions for all materials used.

**CAUTION: KEEP OUR OF REACH OF CHILDREN**

**DO NOT TAKE INTERNALLY**

**DO NOT FREEZE**

MADE IN THE U.S.A